


On/Off Switch

AXON Body 2 operating functions


Lens



On/Off Switch

AXON BODY 2 OPERATING FUNCTIONS

Function Button



On/Off Switch

Function Button


AXON Body 2 operating functions

Lens

Speaker

On/Off Switch

Function Button



AXON Body 2 operating functions

Lens


Speaker

On/Off Switch

Function Button

Battery LED

Battery Status Button



AXON Body 2 operating functions

Lens

Speaker


EVENT Button

On/Off Switch


Function Button


Battery LED


Battery Status Button





AXON Body 2 operating functions
















- To start recording video, double tap the EVENT Button.


Recording videos



- To stop recording, press and hold the EVENT Button.

Recording videos

Operating MODES



Operation LED	Operating Mode
Solid Red	Booting Up
Blinking Green	Buffering
Blinking Red	Recording

58

Adding Markers



- Press and release the function button.




Battery LED	Battery Life Indicator
Solid Green	41 – 100%

Battery Life



Battery LED	Battery Life Indicator
Solid Green	41 – 100%
Solid Yellow	20 – 40%


Battery Life



Battery LED	Battery Life Indicator
Solid Green	41 – 100%
Solid Yellow	20 – 40%
Solid Red	0 – 19%
Blinking Red & Yellow	Depleted Dead Battery

Battery Life


Indicators during the upload process



Initial connection (momentary)
Solid red (for 20 seconds or fewer)

Camera LED information


Indicators during the upload process



In queue awaiting upload
Solid yellow

Camera LED information


Indicators during the upload process



Uploading data
Blinking yellow

Camera LED information

Indicators during the upload process



Device ready
Solid green

Camera LED information


Indicators during the upload process



**Device not assigned, agency mismatch,
camera set in the offline mode, or device error**
Blinking red

Camera LED information


Indicators during the upload process



**Firmware update, internal battery charging,
extremely low battery, or memory full**
Blinking red and yellow

Camera LED information


Indicators during the upload process



Transfer error, device re-trying to transfer
Blinking green and yellow

Camera LED information


Indicators during the upload process



Network error (no connection)
Blinking red, yellow, and then green (cycling all colors)

Camera LED information

Indicators during the upload process



Axon Dock has no communication with the camera
LED off

Camera LED information
